






With MapeLevel Easy tile levelling system, achieving a perfect floor is even easier and faster. Thanks to the rapid screwing system, MapeLevel Easy can be applied more quickly, considerably reducing overall installation time.

Tile **levelling** is even more **precise**: this allows to prevent any tile lippage guaranteeing a perfect result, even when laying large format tiles.

Versatile and complete, **MapeLevel Easy System** can be used with a wide range of tiles (up to 21 mm thick) and adapts to all laying patterns, with lower consumption rates compared with the traditional wedge systems.

MapeLevel Easy System is mainly made of recycled plastic material, respecting the environment.



Where to use

- For ceramic tiles and stone slabs on floors and walls.
- Particularly recommended for the installation of large format tiles.
- For tiles from 3 to 21 mm thick.

System set



Cap MapeLevel Easy Cap



Spacer MapeLevel Easy Spacer L

A complete range of screw spacers, available in 3 versions (linear, T and X spacers) and 5 different sizes (1, 1.5, 2, 3, 5 mm).



Anti-scratch shield

surface of delicate tiles.

MapeLevel Easy Shield Optional accessory: to be applied under the cap to protect the



Before application



After application





An installation with several **advantages**



Rapid screwing

Thanks to the special rapid-thread screw, the cap spins down the screw faster and with less effort, making the application quicker.



Easy levelling

Tiles can be levelled easily and precisely by simply tightening the cap until obtaining a perfectly flat tiling.



Manual installation and removal

MapeLevel Easy can be installed and removed by hand, without screwers, unscrewers or additional tools.



A complete range of spacers

Available in 3 versions and 5 different thicknesses to suit all application requirements. **MapeLevel Easy Spacers L** are designed to break off below the surface of the tile, for a quick and accurate removal.






Open-view cap design

The exclusive shape of **MapeLevel Easy Cap**, with wide lateral openings, allows the installer to check the tile levelling.



Reusable cap

The disposable elements are easily removed from the caps, which can be used again to install other tiling.



71

82 68

64 60 53

60 56

59 55

49 44 39 33 30 28

100 297 197 192 153 157 117 104 93

330 219 186 149 139 103 91

330 219 192 153 146 109 96 86 71

347 230 192 153 140 104 92 83 68

200 160 157 117 104 93 77

120 330 219

Approximate number of caps and spacers required

Α			Constitution to the Hotton															
10	980		Cross joint installation															
15	650	431																
20	485	322	240															
25	386	256	191	152											_			
30	320			126	105													
40	485	322	240	191		178												
45	430	286	213	170		157	140											
50	386	256	191	152	126	141	125	112										
60	320	212	159	126	105	117	104	93	77				Α					
75	387	256	191	152		125	111	99	82	81								
80	362	240	179	143		117	103	93	77	76	71					В		
90	321	213	159	126		103	92	82	68	67	63	56						
100	287	190	142	113	94	92	82	73	60	60	56	50	44					
120	321	213	159	126		96	85	76	63	60	56	49	44	43				
150	321	213	159	126		92	82	73	60	55	52	46	41	38	34			
180	321	213	159	126		89	79	71	59	52	49	43	38	36	31	28		
200	337	223	167	133		92	81	73	60	53	49	44	39	35	30	27	26	
cm	10	15	20	25	30	40	45	50	60	75	80	90	100	120	150	180	200	В

Consumption rates are approximate and depend on the layout and flatness of the tiles.



EVERYTHING'S **OK**, WITH **MAPEI**

HEAD OFFICE MAPEI SpA Via Cafiero, 22 20158 Milan +39-02-37673.1 mapei@mapei.it mapei.com

